



Instructions for McKrete Installation

Deck Preparation

- A. Clean all foreign matter off deck (mastic, oil, grease, dirt etc....)
- B. Clean and acid etch with Etch & Degreaser
 - 1. DO NOT wet deck prior to etching, pour directly on dry concrete.
 - 2. Use a 1:1 or a 3:1 mix, depending on condition of the concrete.
 - 3. Check pH level of concrete: needs to be no higher than a 9 on pH scale.
 - 4. High pressure wash deck: It is very important to neutralize all acid.

Installation

- A. Secure all areas around the deck to be installed so no over spray will drift onto undesired areas.
- B. If a scratch coat is desired:
 - 1. Mix a thin solution and pour out onto the damp concrete. Use a trowel to spread out evenly.
 - 2. Let dry thoroughly.
 - 3. If you are using **McKrete** to regrade or fill holes, then use the special additive. Stir this additive for approximately 3 minutes, let stand 5 minutes, re-stir, and use.
 - 4. Spray approximately 18" to 24" above deck with 15 lbs of pressure. Always spray on damp deck.
 - 5. Troweler follows sprayer and should begin troweling before the **McKrete** turns dull looking.
 - 6. Troweler will also carry a clean wet sponge to clean trowel.
 - 7. Check for dryness in the shady areas. If you can't indent the material with your thumbnail, then it's dry.
 - 8. Lightly scrape, or with a fluted brick, remove all Surface Imperfections and blow off the loose material.

Sealing the Deck:

- A. Seal the deck with any of the sealers listed in the section described as Sealers for use with **McKrete**.